

```
to limit the fzp scanner ranges
in PID_FAST FZP PID LOOP
0: reduce to small ahead movement range, such as -0.05
4: reduce error threshold, eg 0.01
5: inform PID that FZP range is small, such as 0.1

in PID_FZP
limit the analog output LB and UB
```